

# UNIVERSAL QUICK JOINT CONSTRUCTION MANUAL

## INDEX

Issue 48

June 2011

Section	Issue	Title	Date	Level of Change	Details
1_1	6	Description of the Universal Quick Joint <i>GMSL</i>	Mar 07		
1_2	1	Advice on Testing to be carried out during jointing <i>GMSL</i>	Sep 02		
2_1	12	Introduction <i>GMSL</i>	Apr 10		
2_2	16	Single Armor Cable Preparation <i>GMSL</i>	Jan 11		
2_3	25	Double Armor Cable Preparation <i>GMSL</i>	Feb 11		
2_4	8	Rock Armor Cable Preparation <i>GMSL</i>	Apr 07		
2_5	17	TE SubCom SL12 Armorless Cable Preparation <i>TE SubCom</i>	Jun 10		
2_6	12	ASN S3 Cable Preparation <i>ASN</i>	Nov 09		
2_7	15	URC2 Cable Preparation <i>ASN</i>	Dec 06		
2_8		Deleted			
2_9	12	Pirelli Multi-fiber Cable Preparation <i>GMSL</i>	Feb 09		
2_10	18	NSW CT Cable Preparation <i>GMSL</i>	Jul 10		
2_11	20	ASN URC-1 Cable Preparation <i>ASN</i>	<b>Apr 11</b>	Minor	Amendments to tool kits & procedure with no tape.
2_12	3	AEI CSDH Cable Preparation <i>GMSL</i>	Oct 02		
2_13	4	NSW SAI Cable Preparation <i>GMSL</i>	Nov 06		

# UNIVERSAL QUICK JOINT CONSTRUCTION MANUAL

## INDEX

Issue 48

June 2011

Section	Issue	Title	Date	Level of Change	Details
2_14	1	Cable Armour Transition Procedures <i>TE SubCom</i>	Dec 06		
3_1	8	Joint Assembly Procedure when using KIT30000 & KIT30001 <i>TE SubCom</i>	Sep 06		
3-1/1	2	Joint Assembly Procedure when using KIT30002 <i>TE SubCom</i>	Feb 07		
3_2	22	Fiber Management & Storage when using KIT30000 & KIT30001 <i>GMSL</i>	Feb 11		
3_2/1	9	Fiber Management & Storage when using KIT30002. <i>TE SubCom</i>	Feb 11		
3_3	17	Application of the Heatshrink Insulation <i>TE SubCom</i>	Sep 07		
4_1	20	Single Armor Reinstatement and Protection <i>GMSL</i>	<b>May 11</b>	Minor	URC-1 added to Tables 1 & 2
4_2	31	Double Armor Reinstatement and Protection <i>GMSL</i>	Feb 11		
4_3	10	<ul style="list-style-type: none"> <li>• LW/SPA/LWP Joint Closure</li> <li>• Screen Reinstatement for ASN 14mm Cables</li> </ul> <i>ASN</i>	Mar 07		
4_4	5	Screen Isolation Heatshrink Installation for ASN S3 STP Cables <i>ASN</i>	Sep 99		
4_5		Reserved for Transition Reinstatement and Protection			
4_6	4	Rock Armor Reinstatement and Protection <i>GMSL</i>	Aug 07		

# UNIVERSAL QUICK JOINT CONSTRUCTION MANUAL

## INDEX

Issue 48

June 2011

Section	Issue	Title	Date	Level of Change	Details
5_1	9	Stripping of Ultra-Violet Light Cured Unit Fiber Structure for TE SubCom SL12 (SL100/SL101) cables <i>TE SubCom</i>	Mar 07		
5_2	6	Fiber Splicing using the Sumitomo Type 35SE Splice Unit <i>GMSL</i>	Nov 03		
5_3	4	Operating Procedures for the 20 Tonf Ferrule Press BD 011 L 01 <i>GMSL</i>	Jan 00		
5_4	6	Elastomer Stripping <i>TE SubCom</i>	Feb 10		
5_5	5	Stripping of TE SubCom SL12 Loose Tube Cable <i>TE SubCom</i>	Aug 08		
App 1	10	Tools and Equipment for the Universal Quick Joint	Feb 09		
App 2	3	List of Consumable Materials	Mar 04		
App 3	11	Universal Quick Joint Kit Lists	Nov 10		

**Dates in BOLD TYPE indicate new issue**